



Notes:

- △ Prep for #8 wood or 8-32 machine screws.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See Spec.2002CPDP/2002CPDP-Q for additional lock details.

Standard 2002CPDP/2002CPDP-Q
 Quiet Pocket Door Edge Pull
 Lock Only, All Backsets

T-ALH.2002CPDP.CPDP-Q