



Functions	A	B	C	D	E	F
8822ML	●	●	●	●		●
8824ML	●	●				●
8825ML	●			●		
8839ML	●	●		●	○	

● Required Holes  
○ Optional Holes



**Important Notes:**

- ① Insert backset here 1 1/2", 1 3/4", 2", 2 1/4"
- ② ASA strike mounted 3/8" ABOVE centerline of lock
- ③ Prep for #12 wood or 12-24 machine screws (Lock and Strike)
- ④ Thru bolting holes **ONLY** if required. See trim manufacturers standard template for details.  
Accurate lock's accommodates 1 1/2" to 1 11/16" center to centers and up to 1/4" dia. post.  
If there are any additional questions about the thru-bolting, please contact our office.
- ⑤ Knob/Lever, Thumbturn and ER holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

**Additional Notes:**

- a) **Responsibility:** Door and frame manufacturers are responsible for providing
- adequate construction or re-inforcement for proper installation of hardware shown.
- c) See catalog / spec sheets for additional lock details

Standard 8800ML Magnetic Lever x Lever or Knob x Knob Template - All Backsets

T-ALH.8800.ML